

Power Equipment	Description
131.8000	Craftsman 6 HP 24" Riding Lawnmower
131.8140	Craftsman 24" Riding Lawnmower
131.8190	Craftsman 5 HP 24" Riding Lawnmower
131.8250	Craftsman 5 HP 26" Riding Lawnmower
131.8260	Craftsman 6 HP 26" Riding Lawnmower
131.8282	Craftsman 6 HP 26" Riding Lawnmower
131.8460	Craftsman 10 HP Power Unit
131.8570	Craftsman 10 HP Power Unit
131.8750	Craftsman 10 HP Power unit
131.96261	Craftsman 7 HP 26" Riding Lawnmower
131.96285	Craftsman 6 HP 26" Riding Lawnmower
131.96300	Craftsman 6 HP 26" Riding Lawnmower
131.96361	1971 Craftsman 36" Riding Lawnmower
131.96502	Craftsman 7 HP 36" Riding Lawnmower
131.96510	Craftsman 7 HP 36" Riding Lawnmower
131.96601	Craftsman 7 HP 36" Riding Lawnmower
131.96602	Craftsman 7 HP 36" Riding Lawnmower
131.96712	Craftsman 10 HP 36" Riding Lawnmower
131.96830	Craftsman 7 HP 26" Riding Lawnmower
131.96860	Craftsman All Electric, 32" Riding Lawnmower
131.96891	1974 Craftsman 7 HP 26" Recoil Start Riding Lawnmower
131.96920	1973 Craftsman 7 HP 26" Recoil Start Riding Lawnmower
131.96960	1974 Craftsman 8 HP 36" Recoil Start Riding Lawnmower
131.969802	1976 Craftsman 10 HP 36" 331CC Riding Lawnmower
131.969930	1976 Craftsman 10 HP 36" 331CC Riding Lawnmower
247.270170	Sears MTD Yard Bug 8.5HP Automatic, 27.5" Deck
247.270250	Craftsman Utility Vehicle
502-250840	1977 Sears LT/10 10 HP, 3 Speed, 42" Cut Lawn Tractor
502.250891	1977 Craftsman 10 HP 36" Electric Start Lawn Tractor
502.250892	1977 An update to 502.250891
502.250893	1977 An update to 502.250892 With 11 HP Engine
502.251220	Craftsman 10 HP 30" 5 Speed Rear Engine Rider
502.254140	Craftsman 10 HP 30" 5 Speed Rear Engine
502.254160	Craftsman 10 HP 30" 5 Speed Rear Engine
502.254172	Craftsman 10 HP 30" 6 Speed Rear Engine w/Bagger
502.254280	Craftsman 11 HP 36" 4 Speed Lawn Tractor

502.254970	1970 Craftsman 14 HP 46" 6 Speed Lawn Tractor
502.255020	1991 Craftsman 10 HP 30" 5 Spd Rear Eng. Mulcher/Mower
502.255071	Craftsman 10 HP 30" 5 Spd Rear Eng. Mulcher/Mower
502.255111	Craftsman 12 HP, 38", 5 Speed Lawn Tractor
502.255112	Craftsman 12 HP 38" Electric Start Lawn Tractor
502.255140	Sears 10HP 36" Electric Start Lawn Tractor
502.255141	1978 Sears LT 10, 10HP Electric Start Lawn Tractor
502.255142	Sears 10 HP Electric Start Lawn Tractor
502.255143	1977 Sears LT 10, 10HP Electric Start Lawn Tractor
502.255150	1978 Sears 11 HP Electric Start , 42" Lawn Tractor
502.255180	1990 Craftsman 12.5 HP 40" 6 Speed Lawn Tractor
502.255190	1990 Craftsman 12 HP 40" 6 Speed Lawn Tractor
502.255290	Sears LT 11 Lawn Tractor LT11/36 36" deck
502.255292	Sears LT 11 Lawn Tractor
502.255321	Sears LT 16/42 Lawn Tractor
502.255380	Craftsman 36" 11 HP Lawn Tractor
502.255633	Craftsman 30" 8 HP Lawn Tractor
502.255641	Craftsman 30" 10 HP Electric Start Lawn Mower
502.255650	Craftsman 30" 11 HP Electric Start Lawn Mower
502.255651	Craftsman 30", 11 HP, Rear Engine Lawn Mower
502.255660	Craftsman 11 HP 36" Electric Start Lawn Mower
502.255750	Craftsman 11 HP 40" Riding Lawn Tractor
502.255752	Craftsman 11 HP 40" Riding Lawn Tractor
502.255790	Craftsman 10 HP 36" Riding Lawn Tractor
502.255791	Craftsman 10 HP 36" Riding Lawn Tractor
502.256071	Craftsman 8 HP 30" Riding Lawn Tractor
502.256125	Craftsman 8 HP 30" Electric Start Riding Lawn Mower
502.256172	1984 Craftsman 10 HP 30" Electric Start Riding Lawn Mower
502.257010	Sears 11 HP Yard And Garden Tractor
502.257040	Sears 16 HP Yard And Garden Tractor
502.257310	Craftsman 8 HP, 30", 5 Speed, Rear Engine
502.25801	Sears LT/10 Lawn Tractor
502.25891	Sears LT/10 Lawn Tractor
502.259120	Sears Companion 5HP 3 Speed 25" Recoil Start Rider
502.602180	Sears 18HP Garden Tractor
502.608251	Sears LT 8 36" 5 Speed Lawn Tractor
502.81381	1971 Craftsman 6 HP, 25" Riding Lawn Mower

529.70200	1973 Lawn Scout 42" Riding Mower
536.250820	Craftsman 8 HP 32" Electric Start Riding Lawnmower
536.250823	Craftsman 8 HP 32" Electric Start Riding Lawnmower
536.250930	Craftsman 8 HP 36" Electric Start Riding Lawnmower
536.252570	Craftsman 16.5 HP OHV, 43" All Wheel Steer, Hydrostatic Drive
536.255212	Sears 10 HP 36" Lawn Tractor Owner's Manual
536.255861	Craftsman 12.5 HP All Wheel Steer, 40 ", 5 speed
536.81330	Craftsman 8 HP, 36 "
536.81360	1971 Craftsman 8 HP, 36 "
536.963100	Craftsman 32" Riding Rotary Mower
536.96330	Craftsman 8 HP 36" 306 CC Riding Rotary Mower
536.96360	1973 Craftsman 8 HP 36" 306 CC Riding Rotary Mower
536.96361	Craftsman 8 HP 36" 306 CC Riding Rotary Mower
536.96362	1973 Craftsman 8 HP,306 CC, 36" Riding Rotary Mower
917.25010	1967 Custom 6 Garden Tractor
917.25010	1967 Custom 6 Garden Tractor
917.25020	1967 Custom 6 Garden Tractor
917.25020	1967 Custom 6 Garden Tractor
917.250261	Sears 20 HP 50 Inch Garden Tractor
917.25040	1972 Sears Compact 8E Tractor
917.25050	1971 Sears Compact 8E Tractor
917.250510	Craftsman 3in1 19.5 HP Twin, 46", 6 Speed
917.250520	Craftsman 3in1 19.5 HP Twin, 46", Hydrostatic
917.25060	Sears Custom 10XL Tractor
917.25070	1972 Sears Custom 10E Tractor
917.25080	Custom 6 Garden Tractor Recoil
917.250831	Craftsman 10 HP 36" Riding Lawn Tractor
917.25090	Custom 6 Garden Tractor Electric
917.25100	Sears 10 HP Suburban Tractor - Recoil
917.25110	Sears 10 HP Suburban Tractor - Electric
917.25121	1967 Sears 12HP Suburban Tractor - Electric Start
917.251492	Craftsman EZ3 18.5 HP 46" Riding Lawn Tractor
917.251550	Craftsman 22.5 HP, 6 Speed, 50" Riding Garden Tractor
917.25160	1976 Sears 14/6 Garden Tractor
917.25161	1977 Sears 14/6 Garden Tractor
917.25170	Sears 16/6 Garden Tractor
917.25180	1976 Sears 16/6 Garden Tractor

917.25181	Sears 16/6 Twin Garden Tractor
917.25191	1976 Sears 18/6 Twin Garden Tractor
917.25201	1972 Sears Suburban 15
917.25220	1967 Sears Custom 7 Tractor
917.252500	Craftsman 13.0 HP, 42", 6 Speed Riding Lawn Tractor
917.252501	Craftsman 13.0 HP, 42", 6 Speed Riding Lawn Tractor
917.252560	1994 Craftsman 19 HP Twin 3 IN one, 42", 6 Speed
917.252561	1995 Craftsman 19 HP Twin 3 IN one
917.252590	1995 Craftsman 15.5 HP, 3 IN one, 42", Hydrostatic
917.252610	Craftsman 15 HP, 3 IN one, 42", Hydrostatic
917.252631	Craftsman LTV 10 Varidrive Lawn Tractor
917.252635	1982 Craftsman LTV 10 Varidrive Lawn Tractor
917.252671	LTV 10 Varidrive Tractor
917.252681	LTV 11 Varidrive Tractor
917.252683	Sears LTV 11 Varidrive Lawn Tractor
917.25300	1967 Sears Super 12 Hydro-Trac
917.25311	1968 Sears SS-12 Tractor
917.25340	1968 Suburban 12
917.25350	1968 Suburban 12
917.25370	1971 Sears Suburban 12 Tractor
917.253712	1981 GTV 11 Varidrive Garden Tractor
917.253715	1982 GTV 11 Varidrive Garden Tractor
917.253724	1981 Sears GTV 16 Twin VariDrive
917.253735	Sears GTV 18 Twin VariDrive
917.253744	Sears GT 18 6 Speed
917.25381	1972 Sears SS - 15 Tractor
917.25420p	1968 Sears Custom 10XL
917.254220	Craftsman LT 10HP, 4 Speed, 36" Mower
917.254230	1987 LT 11/38, 11 HP, 38" Mower Riding Lawn Tractor
917.254240	1987 LT 12/38, 12 HP, 38" Mower Riding Lawn Tractor
917.254241	1987 LT 12/38 12 HP Craftsman II 38", 6 Speed
917.254244	1987 LT 12/38 12 HP Craftsman II 38", 6 Speed
917.254270	Sears 11HP, 36", Lawn Tractor
917.254274	1988 Craftsman LT 11 HP 4 Speed - 36" Mower
917.254310	1987 YT 14 Twin 5 Speed 38" Mower Tractor
917.254321	1988 Craftsman YT 16 Twin 5 Speed 44" Yard Tractor
917.25440	1968 Sears Custom 7 HP tractor parts

917.254410	1986 Sears GT-18 Twin, 6 Speed, 44" Garden Tractor
917.254430	Sears GT-20 Twin, 44", 6 Speed Garden Tractor
917.254520	1990 Sears 12 HP 38" 5 Speed
917.254530	1991 Sears 12 HP 38" 5 Speed
917.254551	Craftsman LT 12, 12 HP, 38", 6 Speed
917.254622	1989 Craftsman LT 12, 12 HP, 38", 5 Speed
917.254640	1988 Craftsman LT 12/38 12 HP, 38", 6 Speed
917.254641	1989 Craftsman LT 12/38 12 HP, 38", 6 Speed
917.254670	Craftsman LT 11/36 11 HP, 36", 4 Speed
917.25470o	1970 Custom 10XL Electric Start Tractor
917.25470p	1970 Custom 10XL Electric Start Tractor
917.254750	Craftsman 12.5 HP, 38", 5 Speed
917.254791	Craftsman 12.5 HP, 38", 5 Speed Lawn Tractor
917.254812	1981 Sears FF/18 HydroDrive Garden Tractor
917.254830	FF/24 HydroDrive Garden Tractor
917.254860	1993 Craftsman 18 HP Twin, 42", 5 Speed Lawn Tractor
917.25490	1969 Sears Custom 8XL
917.254920	1990 Craftsman 12 HP 38" Deck 6 Speed Lawn Tractor
917.25500	1969 Sears Hydro-Trac 12
917.25501	1970 Sears Hydro-Trac 12
917.25510	1969 Sears SS-12
917.25511	1970 Sears SS-12
917.255120	LT 8/36 Lawn Tractor
917.255130	Craftsman 10 H.P. 36" Riding Lawn Tractor
917.255131	Sears 10 H.P. 36" Riding Lawn Tractor
917.25520	1969 Sears Suburban 12
917.255260	Sears 8 HP 36" Riding Lawn Tractor, Electric Start
917.255270	Sears 10 HP 36" Riding Lawn Tractor, Electric Start
917.2552702	Sears 10 HP 36" Riding Lawn Tractor, Electric Start
917.2552703	Sears 10 HP 36" Riding Lawn Tractor, Electric Start
917.255273	Sears 10 HP 36" Riding Lawn Tractor, Electric Start
917.255274	1981 Sears 10 HP 36" Riding Lawn Tractor, Electric Start
917.255275	1982 Sears 10 HP 36" Riding Lawn Tractor, Electric Start
917.255330	Sears 10 HP 36" Riding Lawn Tractor, Electric Start
917.255340	Sears LT8, 8HP, 36", Varidrive Lawn Tractor
917.255370	Sears 11 HP 36" Riding Lawn Tractor, Electric Start
917.255371	1983 Sears 11 HP 36" Riding Lawn Tractor, Electric Start

917.255373	Sears 11 HP 36" Riding Lawn Tractor, Electric Start
917.255410	1981 Sears LT 10 10 HP 36" Riding Lawn Tractor
917.255430	1993 Craftsman 12.5 HP 6 Speed 42" Lawn Tractor
917.255440	1993 Sears 12.5 HP 6 Speed 42" Lawn Tractor
917.255450	1993 Craftsman 6 Speed 14 HP 3in1
917.255470	1993 14 HP 38" Sears Tractor
917.25550	1969 Sears Suburban 12
917.255540	1991 Craftsman 14HP Twin, 38", 6 Speed Lawn Tractor
917.255560	1991 12.0 HP IC Electric Start 38" Mower Deck 5 Speed
917.255561	1992 12.0 HP IC Electric Start 38" Mower Deck 5 Speed
917.255572	Craftsman 12.5 HP 6 Speed 38" Lawn Tractor
917.255581	1992 Craftsman 12.5 HP, 3In1, 6 Speed, 42" Lawn Tractor
917.255723	1985 Sears 10HP 36" Riding Lawn Tractor
917.255726	1986 Sears 10HP 36" Riding Lawn Tractor
917.255727	Sears 10HP 36" Riding Lawn Tractor
917.255732	1985 Craftsman 11HP 38" Riding Lawn Tractor
917.255741	12 HP 38" Riding Lawn Tractor, Electric Start
917.25580	1970 Sears Custom 8E
917.255812	1985 Sears YT 14 Twin 5 Speed
917.255850	1986 Sears YT 16 Twin Automatic
917.25590	1971 Sears Custom 10 XL
917.255910	Sears GT-18 Twin, 6 Speed Garden Tractor
917.2559101	Sears GT-18 Twin, 6 Speed. 44" Deck, Garden Tractor
917.255912	1986 Sears GT-18 Twin, 6 Speed, Garden Tractor
917.255913	1987 Sears GT-18 Twin, 6 Speed. 44" Deck, Garden Tractor
917.255914	1988 Sears GT-18 Twin, 6 Speed. 44" Deck, Garden Tractor
917.255919	Craftsman GT-18 Twin, 6 Speed. 44" Deck, Garden Tractor
917.255920	1989 Craftsman 18 HP Twin 6 Speed 44" Deck
917.255930	1991 Craftsman 18 HP Twin 6 Speed 44" Deck
917.255942	1992 Craftsman 18 HP Twin 6 Speed 44" Deck
917.255950	Craftsman 18 HP Twin 6 Speed 44" Deck
917.255970	1993 Craftsman II Gold 18 HP 44"
917.255980	Craftsman 18 HP 6 Speed 44" Deck
917.255981	Craftsman 18 HP 6 Speed 44" Deck
917.25610	1970 Sears Super 14 Tractor
917.25620	1970 Sears Suburban 14
917.256220	Craftsman 12 Hp 36" 5 Speed Lawn Rider

917.25630	1972 Sears Suburban 12
917.256321	1990 Craftsman 12 Hp 36" 5 Speed
917.25640	1970 Sears Super 14 Tractor
917.256420	1996 Craftsman Ez3, 15.5 HP, 42" Deck, 6 Speed
917.256501	1996 Craftsman 13.5 HP, 42" Deck, 6 Speed
917.256510	1995 Craftsman Gold, 15.5 HP, 42" Deck, 6 Speed
917.256522	Craftsman EZ3 15.5HP 42" 6 Speed
917.256544	1996 Craftsman EZ3 15HP 42" 6 Speed
917.25660	Craftsman 3in1, 15.5HP, 42", Automatic Lawn tractor
917.256660	1996 Craftsman EZ, 19 HP, 46" Deck 6 Speed
917.256670	1996 Craftsman EZ, 19 HP, 46" Deck Hydrostatic
917.256711	Craftsman EZ, 19 HP, 46" Deck
917.257020	1978 Sears GT-11 Varidrive
917.257030	1978 Sears Varidrive GT-14 Garden Tractor
917.257050	1978 Sears GT-16, 6 Speed Garden Tractor
917.257060	1977 Sears GT-18 Garden Tractor
917.257061	1977 Sears GT-18 Twin Tractor
917.257070	1978 Sears GT-18 Twin HydroTractor
917.257080	1978 Sears GT-19.9 Twin Tractor
917.257081	Sears GT-19.9 Twin Tractor
917.257090	1978 Sears GT-16 Varidrive Tractor
917.257091	Sears GT-16 Varidrive Tractor
917.25710	1972 Sears LT/8E
917.257120	Sears GT 18
917.25720	1972 Sears ST/10 Garden Tractor
917.25721	1973 Sears ST/10 Garden Tractor
917.257211	1992 Craftsman 12HP OHV, 5 Speed, 38"
917.257290	1993 Craftsman 12.5 / IC, 5 Speed, 38"
917.25730	1972 Sears ST/12 Tractor
917.25731	1973 Sears ST/12 Tractor
917.25733	1974 Sears ST/12 Tractor
917.25734	1974 Sears ST/12 Tractor
917.25740	1973 Sears ST/16 Single OHV Tractor
917.25741	1978 Sears 12 HP 38" Riding Lawn Tractor
917.25743	1974 Sears ST/16 Single OHV Tractor
917.25750	1972 Sears SS-16 Garden Tractor
917.25751	1973 Sears SS/16 Garden Tractor

917.25752	1974 Sears SS/16 Twin Tractor
917.257550	Craftsman 3in1, 18HP, 42", 5 Speed Lawn tractor
917.257560	Craftsman 3in1, 14HP, 42", 6 Speed Lawn tractor
917.257620	1993 Craftsman 12.5HP, 38", 5 Speed Lawn tractor
917.257621	Craftsman 12.5HP, 38", 5 Speed
917.257641	1993 Craftsman 3in1, 15.0HP, 42", 6 Speed Lawn tractor
917.257645	Craftsman 3in1, 15.0HP, 42", 6 Speed Lawn tractor
917.257651	1994 Craftsman 3in1, 15.5HP, 42", 6 Speed Lawn tractor
917.257660	Craftsman 3in1, 15.5HP, 42", Hydro Lawn tractor
917.25770	Sears LT/8E Lawn Tractor
917.257730	1994 Craftsman 18HP Twin, 44", Hydrostatic Garden Tractor
917.25781	1974 Sears LT/10E Lawn Tractor
917.25782	Sears LT/10E Lawn Tractor
917.25790	1074 Electric Lawn Mower
917.25840	1974 Sears LT/10E 36" Mower (Same as 25841)
917.25841	1974 Sears LT/10E 36" Mower (Same as 25840)
917.25842	Sears LT/10E
917.25843	Sears LT/10E
917.258492	1992 Craftsman 42" 18.0 HP Twin 5 Speed Lawn Tractor
917.25860	1974 Sears ST/12 Tractor
917.258661	Craftsman EZ3, 46" 19.5 HP 6 Speed Lawn Tractor
917.25873	1975 Sears ST/16 Garden Tractor
917.25884	1975 Sears SS/16 Garden Tractor
917.258860	1996 Craftsman EZ3 18.5 HP, 46", 6 Speed
917.25920	1975 Sears ST/10 X Garden Tractor
917.25921	1975 Sears ST/10 X Garden Tractor
917.259250	Sears 26" Rear Engine 7 HP
917.25930	1976 Sears ST/12 Garden Tractor
917.25940	1976 Sears ST/16 Single OHV Tractor
917.25950	1976 Sears SS/16 Twin Garden Tractor
917.259521	Craftsman EZ3 15.5 HP, 42", 6 Speed
917.259566	Craftsman EZ3
917.259590	1997 Craftsman EZ3 15.5 HP
917.25961	1976 Sears SS/18 Twin Garden Tractor
917.270311	1998 Craftsman 12.5 HP 38" 5 Speed Lawn Tractor
917.270514	1999 Craftsman EZ3 14.5 HP, 42", 6 Speed Lawn Tractor
917.270532	2000 Craftsman 14.5 HP, 42", 6 Speed Lawn Tractor



917.270660	1999 Craftsman EZ3 15.5 HP, 42", Automatic Lawn Tractor
917.270771	2000 Craftsman EZ3 19 HP, 42", 6 Speed Lawn Tractor
917.270810	1997 Craftsman EZ3 19.5 HP, 42", 6 Speed
917.270820	1997 Craftsman EZ3 19.5 HP Hydro
917.270821	1998 Craftsman EZ3 19.5 HP, Hydro, 42"
917.270940	2000 Craftsman EZ3 20.0 HP, Automatic, 42"
917.271020	1997 Craftsman EZ3 15.5 HP, Automatic, 42"
917.271120	Craftsman EZ3 16.5 HP, Hydro, 42"
917.271825	Craftsman 19.5 HP 42" Automatic Lawn Tractor
917.271830	2000 21.0 HP 42"Mower 6 Speed
917.271840	21.0 HP 42" Mower Auto
917.272200	Craftsman EZ3, 25 HP, 46" Mower, Automatic Lawn Tractor
917.272201	Craftsman EZ3, 25 HP, 46" Mower, Automatic Lawn Tractor
917.272350	2003 Craftsman 15.5 HP 42" 6 Speed Lawn Tractor
917.272410	2001 Craftsman 18 HP 42" 6 Speed Lawn Tractor
917.272464	2002 Craftsman 21.5 HP, 42", Automatic Garden Tractor
917.273011	1998 Craftsman EZ3, 20 HP, 46", 6 Speed Lawn Tractor
917.273030	1999 Craftsman EZ3, 20 HP, 46", 6 Speed Lawn Tractor
917.275044	2002 Craftsman 23.0 HP, 50", Automatic Garden Tractor
917.275180	Craftsman 19.0 HP, 42", Automatic Garden Tractor
917.276070	2003 Craftsman 26.0 HP, 48", 6 Speed Garden Tractor
917.276080	2003 Craftsman 26.0 HP, 48", Automatic Garden Tractor
917.276090	2004 Craftsman 25.0 HP, 54", 6 Speed Garden Tractor
917.27621	2004 Craftsman 22.0 HP, 54", 6 Speed Garden Tractor
917.27631	2004 Craftsman 24.0 HP, 48", 6 Speed Garden Tractor
917.27633	2004 Craftsman 27.0 HP, 54", 6 Speed Garden Tractor
917.27634	2005 Craftsman 27.0 HP, 54", Automatic Garden Tractor
917.27635	2005 Craftsman 25.0 HP, 48", 6 Speed Garden Tractor
917.59101	David Bradley Riding Tractor
917.603200	1982 Sears 20T Garden Tractor
917.60601	1959 DB Suburban 5.75 (Manual Start)
917.60602	1959 DB Suburban 5.75 (Electric Start)
917.60603	1959 DB Suburban Riding Tractor
917.60616	1961 DB Suburban 725 (Manual Start)
917.60617	1961 DB Suburban 725 (Electric Start)
917.60619	1967 David Bradley Suburban 600
917.60623	1963 Suburban 725 (Manual Start)

917.60624	1963 Suburban 725 (Electric Start)
917.60644	1965 Sears Suburban 8 HP Recoil
917.60645	1965 Sears Suburban 8 HP Electric
917.60646	1965 Sears Suburban 10 HP Electric
917.8360	1964 Craftsman 36" 6 HP Rotary Mower, Recoil
917.8370	1964 Craftsman 36" 6 HP Rotary Mower, Electric
917.99400	1966 Suburban 10 Recoil Start
917.99410	1966 Suburban 10 Electric Start
917.99420	1966 Sears Suburban 12
917.99520	Sears Custom 6 (Recoil Start)
917.99530	Sears Custom 6 (Electric Start)
917.99800	1966 Sears Custom 600 Recoil
917.99801	Sears Custom, 6 HP, 4 Speed, Electric Start Tractor
917.99810	1966 Sears Custom 600 Electric
917.99811	Sears Custom, 6 HP, 4 Speed, Recoil Start Tractor
944.603280	Craftsman 18.0 HP. 44", 6 speed Garden Tractor
944.606090	Craftsman 18.0 HP. 42", 5 speed Lawn Tractor
944.607280	Craftsman 18.0 HP. 44", 6 speed Garden Tractor
944.607480	Craftsman 18.0 HP. 44", 5 speed Lawn Tractor
GT180AR	1984 Roper 18 HP, 6 Speed Garden Tractor
GT180BR	Roper 18 HP Garden Tractor
GT180BT	Roper 18 HP Garden Tractor
L0262BR	Roper 10 HP, Varidarive, 36" Riding Lawn Mower
L8212AR	1982 Roper 8HP, 36" Lawn Tractor
LT120CR	Roper 12 HP Lawn Tractor
TO2211RO	1973 Roper 10 HP Garden Tractor
TO2231RO	1973 Roper RT-10 Tractor
TO2241R1	1974 Roper RT-10 Tractor
T32231R0	Roper RT-13 Tractor
T32241R2	1979 Roper RT 13 Garden Tractor
T32241R4	1977 Roper RT 13 Garden Tractor
T62231RO	Roper RT-16 Tractor
T63241R1	Roper RT-16T Tractor
T9329AR	1979 Roper 20T Tractor
YT120AT	Roper 12 HP Yard Tractor
YT140AR	Roper 14 HP Yard tractor
YT160BT	1984 Roper 16 HP Yard Tractor

YT160CT	Roper 16 HP Yard Tractor
YTH120AR	Roper 12 HP Hydrostatic Yard Tractor
YTH160DR	Roper 16 HP Hydrostatic Yard Tractor
YTH160ET	Roper 16 HP Hydrostatic Yard Tractor

Attachments	Description
100.26210	Sears Hydraulic Loader
100.26230	Sears Hydraulic Loader
100.262301	Sears Hydraulic Loader
100.26231	Sears Dual Wheel Spacer Kit
131.80371	32" Craftsman Snow Thrower Attachment
131.81361	36" Craftsman Side Discharge Rotary Mowing Unit
131.81362	36" Craftsman Side Discharge Rotary Mowing Unit
190-425A-100	Utility Cart
190-425A-190	Utility Cart
190-491-000	36" Snow Thrower Attachment
23.12.68	Rear Wheel Weights
235.264444	38" Snowblade (for LT8 & LT10 Tractors)
235.264490	42" Snowblade
242.75251	Tractor Mounted Compost Mill
25143	Wiring Kit For Electric 3-Point Hitch
258.264501	Lawn Vac
26431	Rear Wheel Weights
26439	Rear Wheel Weights
100.26210	Sears Hydraulic Loader
100.26230	Sears Hydraulic Loader
100.262301	Sears Hydraulic Loader
100.26231	Sears Dual Wheel Spacer Kit
131.80371	32" Craftsman Snow Thrower Attachment
131.81361	36" Craftsman Side Discharge Rotary Mowing Unit
131.81362	36" Craftsman Side Discharge Rotary Mowing Unit
190-425A-100	Utility Cart
190-425A-190	Utility Cart
190-491-000	36" Snow Thrower Attachment
190-608	Agri-Fab Sleeve Hitch
45.01841	Utility Cart
45.01862	40" Tine De-Thatcher (Pull Behind)

45.0211	Broadcast Spreader
45.0221	38" Lawn Sweeper
45-02401	Utility Cart
45.0268p	Box Scraper/Grader Blade Parts List
402.264100	Lawn Vacuum Collector Attachment
402.98701	Sears Hauling Dump Cart
486.240301	30" Craftsman Lawnsweeper
486.242051	Craftsman Row Crop Cultivator
486.242411	Craftsman Box Scraper / Grader Blade
486.24275	Craftsman Tractor Snow Cab
486.24336	Craftsman 36" Spike Aerator
486.244021	48" Dozer Blade
486.244040	Sears 48" Snow Blade
486.244062	1992 Sears 48" Snow Blade
486.244071	42" Sears Snow Blade
486.244120	48" Dozer Blade
486.244280	48" Dozer Blade
486.24443	Craftsman 42" Dozer Blade
486.24535	Craftsman Sleeve Hitch
486.246211	Craftsman Tractor Brush Guard
486.248463	Craftsman 46" - 2 Stage Snow Thrower
486.24847	Craftsman Front Scoop Tractor Attachment
486.254020	46" Dozer Blade & Lift Mechanisms
486.254021	46" Dozer Blade
486.254051	Lift Kit For 46" Dozer Blade #486.254021
486.254071	42" Snow Blade
486.254072	42" Snow Blade
486.26457	42" Snow Blade Bracket
486.26459	42" Snow Blade
486.290850	Sears 6-Tang Universal Cultivator
502.249274	Craftsman Grass Bagger For 30" Rear Engine Riders
502.249370	Sears Grass Catcher For Rear Engine Riders
502.249380	Sears Grass Catcher For Rear Engine Riders
502.253610	36" Rotary Mower For Yard And Garden Tractors
502.269280	25" Craftsman Grass Catcher For Rear Engine Mowers
502.269290	30" Craftsman Grass Catcher For Rear Engine Mowers
521.244701	Vacuum Attachment

521.264703	Sears 5 HP Vacuum Collector
536.79962	Push Lawn Sweeper w/Tractor Upgrade
536.79963	30" Craftsman Push Lawn Sweeper w/Tractor Upgrade
536.82340	Push Sweeper Hitch For Tractor Use
580.320690	Tractor Mounting Kit For Pulley Driven Portable Alternator
580.327710	2500 Watt Pulley Driven Portable Alternator (Same as 720)
580.327720	4000 Watt Pulley Driven Portable Alternator (Same as 710)
610.240841	Craftsman 36" Lawn Roller
610.24350	36" Lawn Aerator
610.26355	Sears 6 Cu. Ft. Hauling Cart
662.264220	Front Mount Tote Box for Sears tractors
71.24539	Tow Lawn Finisher
71-25409	Guide Mounting Bracket for 42" Blade # 486.254071
71-26324	Rear Wheel Weights
738-107	Roper 38" Rotary Mower
757.24170	De-Thatcher
757.24233	10" Moldboard Plow
757.245230	Craftsman Sub-Soiler
7580H	Rear Wheel Weights
842.240510	42" Front Mounted Snow Thrower Attachment
842.24071	40" Snow Thrower Attachment
842.252440	Craftsman 5HP 36" Tiller
842.26002	Sickle Bar Mower
842.260032	40" Snow Thrower
842.26005	42" Snow Thrower
842.260051	Sears 42" Snow Thrower
842.260052	42" Snow Thrower
842.260061	36" Snow Thrower
842.260063	36" Snow Thrower
842.26007	36" Snow Thrower
842.260071	40" Snow Thrower
842.260073	40" Snow Thrower
842.26008	40" Snow Thrower
842.26009	36" Snow Thrower
842.260261	36" Snow Thrower
842.26062	40" Snow Thrower
842.260621	40" Snow Thrower

917.242450a	Electric Lift Actuator Kit for Automatics
917.242450g	Electric Lift Actuator Kit for Gear Drives
917.242484	Craftsman 8HP, 30" Sleeve Hitch Tiller Attachment
917.249331	Rear Bagger - 38" For Side Discharge Mower
917.249401	Sears 38" Grass Catcher
917.249483	Sears 38" Mower Grass Catcher
917.249670	Craftsman 42" Mower Grass Catcher
917.250089	Craftsman 42" Mower Grass Catcher
917.249670	36" Mower Head
917.250121	38" Rotary Mower
917.250122	Sears 38" Rotary Mower
917.250129	Conversion Kit For Aluminum to Steel 38" Deck Housing
917.250161	Sears Rotary Snowplow For Custom Tractors (917.252620)
917.250180	Bulldozer-Snowplow For Custom Tractors
917.250181	Bulldozer-Snowplow For Custom Tractors
917.250220	12 Volt Lighting Kit for Custom Tractors
917.250520	38" Rotary Mower for Custom Tractors
917.250540	Snow Thrower Attachment For 10 HP Custom Tractors
917.250550	Bulldozer-Snowplow For Custom Tractors
917.250660	Snow Thrower Attachment for 10 HP Custom Tractors
917.250680	Snow Thrower for Suburban Tractors
917.251012	Sears 36" Rotary Mower Deck
917.251020	Sears Rotary Mower Deck
917.251041	48" Mower Deck
917.251050	42" Rotary Mower
917.251090	Sweep-Holder
917.251240	Cultivator for Riding Tractors
917.251330	Rear Leveler Blade
917.251350	Sears Rotary Snow Plow
917.251351	1967 Sears Rotary Snow Plow
917.251380	Sears Bulldozer-Snowplow For Suburban Tractors
917.251382	Sears Bulldozer-Snowplow For Suburban Tractors
917.251390	Sears Mower Vacuum Collector
917.251392	Rear Leveler Blade
917.25143	Wiring Kit For Electric 3-Point Hitch
917.251450	Sears Electric Start Conversion Kit for 66 to 68 Suburbans
917.251520	1967 Sears Sickle Bar Mower

917.251780	3-Point Hitch For 66-67 Suburban & All Custom Tractors
917.251781	3 Point Hitch
917.251820	39" Rotary Snow Plow
917.251840	Roto-Spader Attachment
917.251860	6 HP Roto Spader
917.251880	8 HP Roto-Spader
917.251883	1978 8 HP Self Powered Roto-Spader Attachment
917.251890	8 HP Roto-Spader
917.252010	38" Rotary Mower for Custom Tractors
917.252031	38" Rotary Mower for Custom Tractors
917.252040	38" Rotary Mower for Custom Tractors
917.252110	40" Disc Harrow
917.252210	Cultivator Tool Bar
917.252240	Cultivator With Sweeps
917.252250	Cultivator With Shovels
917.252280	Sweep Holder With Middlebuster
917.252370	1981 Sears 6 HP 30" Sleeve Hitch Tiller Attachment
917.252380	Seeder And Fertilizer for Sleeve Hitch
917.252420	1982 Sears Electric Assist Kit
917.252421	Electric Lift Assist For GT Tractors 917.255910
917.252490	8 HP 30" Sleeve Hitch Tiller Attachment
917.252620	Sears Rotary Snowplow For Custom Tractors (917.250161)
917.253010a	Moldboard Plow
917.253010b	Moldboard Plow
917.253020	10 Inch Moldboard Plow
917.253050	Three Point Hitch
917.253060	Three Point Hitch
917.253110	Three Point Hitch
917.253120	Sears Sickle Bar Mower
917.253130	Electric 3-point hitch
917.253140	Front Mounting Bracket
917.253150	42" Rotary Mower Deck
917.253151	42" Rotary Mower Deck
917.253160	48" Rotary Mower
917.253161	48" Rotary Mower
917.253170	Front Mounting Bracket
917.253182	Sleeve 3-point Hitch Adapter

917.253230	42" Rotary Mower
917.253240	1973 48 " Rotary Mower
917.253250	42 " Rotary Mower
917.253260	48 " Rotary Mower
917.253310	45 Inch Dozer Blade
917.253311	46 Inch Dozer Blade
917.253330	Bulldozer-Snowplow
917.253331	46" Bulldozer-Snowplow
917.253350	39" Snow Thrower
917.253360	46" Bulldozer-Snowplow
917.253361	Dozer Blade For Suburban Tractors
917.253370	42" Rotary Mower
917.253380	48" Rotary Mower
917.253430	Sears Suburban Tractor Shredder Attachment
917.253540	1976 42" Rotary Mower
917.253550	1976 48" Rotary Mower
917.253551	48" Rotary Mower
917.253570	42" Rotary Mower
917.253572	42" Rotary Mower
917.253580	42" Rotary Mower
917.253581	42" Rotary Mower
917.253582	42" Rotary Mower
917.253590	48" Rotary Mower
917.253591	48" Rotary Mower
917.253592	48" Rotary Mower
917.253642	44" Rotary Mower
917.253645	44" Rotary Mower
917.253650	44" Rotary Mower
917.253660	50" Rotary Mower
917.253950	Sears Tractor jack
917.254020	46" Dozer & Lift For GTV Tractors
917.25410	54" Dozer Blade For Full Feature Tractors
917.256582	42" Rotary Mower
917.256592	48" Rotary Mower
917.26290	Category "O" 3 Point Hitch For "FF" Series Tractors
917.262980	Seeder And Fertilizer for Sleeve Hitch
917.262991	Rear PTO Two Speed Gearbox For "FF" Series



917.263091	Front PTO Kit For "FF" Serries
917.60604	Disc Harrow For Suburban And Custom Tractors
917.60605	Cultivator for David Bradley Suburban Tractor
917.60609	Early David Bradley Dozer Blade
917.60652	Sears Plow For Suburban or Custom Tractors
917.60655	Rotary Mower Deck for Suburban Riding Tractor
917.60656	Sears Sickle Bar Mower
917.60657	Three Point Hitch For Suburbans Prior To 1966
917.62604	Three Point Hitch
917.62606	36" Rotary Mower
917.640680	Snowthrower Attachment for Suburban Tractors
917.643542	42 Inch Rotary Mower
917.643552	48 Inch Rotary Mower
917.99150	Sears Rear-Mount Grader Blade For Custom Tractors
917.99620	36" Rotary Mower
917.99621	12 Volt Lighting Kit for Custom Tractors
922.24173	Hardtop Vinyl Cab
922.24174	Hardtop Vinyl Cab
922.261660	Hardtop Vinyl Cab
9-64009	36" Snow Thrower Attachment
ALS-36 / 48	Anderson MFG. Co. Spreader Parts
C944.123991	Craftsman 38" Mechanical Clutch Mower
C944.619141	8 HP 30" Sleeve Hitch Tiller Attachment
FD-36	36" Gannon Earthcavator
FD-42	42" Gannon Earthcavator
HMN153126	Haban 40" Snow Thrower Attachment
STD365401	Sears Ignition Switch Kit Wiring Diagram
TA0331RO	Front Wheel Weights
TA1331RO	1973 3-Point Hitch
TA1157AR	Electric 3-Point Hitch
TA207AR	Manual 3-Point Hitch
TT2031R	Roper 38" Rotary Mower
TT2131R	Roper 42" Rotary Mower
TT2231R	Roper 48" Rotary Mower
TT508AR	Roper 38" 8 Hp Roto-Tiller Attachment
TT6031R1	Roper 42" Dozer Blade
TT648AR	Roper 39" Snowthrower Attachment

TT728AR

Roper 42" Rotary Mower

TT738AR

Roper 48" Rotary Mower

TX110BR

Roper GT Sleeve Hitch